

## NEW INTERNATIONAL INTERMEDIATES, EFFECTIVE 0000 G.M.T., FEB. 1, 1927.

## EUROPE

EA—Austria  
 EB—Belgium  
 EC—Czechoslovakia  
 ED—Denmark and Faroe Ids.  
 EE—Spain and Andorra  
 EF—France and Monaco  
 EG—Great Britain and Northern Ireland  
 EH—Switzerland  
 EI—Italy  
 EJ—Jugo-Slavia  
 EK—Germany  
 EL—Norway, Spitzbergen and Franz Josef Land  
 EM—Sweden  
 EN—The Netherlands  
 EO—Irish Free State  
 EP—Portugal, Madeira Ids., and the Azores  
 EQ—Bulgaria  
 ER—Rumania  
 ES—Suomi (Finland)  
 ET—Poland, Esthonia, Latvia, Courland and Lithuania  
 EU—U. S. S. R. ("Russia"), including Ukraine  
 EV—Albania  
 EW—Hungary  
 EX—Luxemburg  
 EY—Greece  
 EZ—Zone of the Straits

## ASIA

AA—Arabia  
 AB—Afghanistan  
 AC—China (including Treaty Ports), including Manchuria, Mongolia, and Tibet.  
 AD—Aden  
 AE—Siam  
 AF—French Indo-China  
 AG—Georgia, Armenia and Azerbaijan  
 AH—Hedjaz  
 AI—India (and Baluchistan) and Goa  
 AJ—Japan and Chosen (Korea)  
 AK—(Unassigned)  
 AL—(Unassigned)  
 AM—Federated Malay States (with Straits Settlements)  
 AN—Nepal  
 AO—Oman  
 AP—Palestine  
 AQ—Iraq (Mesopotamia)  
 AR—Syria  
 AS—Siberia, including "Central Asia"  
 AT—Turkey  
 AU—(Unassigned)  
 AV—(Unassigned)  
 AW—(Unassigned)  
 AX—(Unassigned)  
 AY—Cyprus  
 AZ—Persia

## NORTH AMERICA

NA—Alaska  
 NB—Bermuda Id.  
 NC—Canada, Newfoundland and Labrador  
 ND—Dominican Republic  
 NE—(Unassigned)  
 NF—Bahama Ids.  
 NG—Guatemala  
 NH—Honduras  
 NI—Iceland  
 NJ—Jamaica  
 NK—(Unassigned)  
 NL—Lesser Antilles  
 NM—Mexico  
 NN—Nicaragua  
 NO—British Honduras  
 NP—Porto Rico and Virgin Ids.  
 NQ—Cuba and Isle of Pines  
 NR—Costa Rica  
 NS—Salvador  
 NT—Haiti  
 NU—United States of America  
 NV—(Unassigned)  
 NW—(Unassigned)  
 NX—Greenland

NY—Panama  
 NZ—Canal Zone

## SOUTH AMERICA

SA—Argentina  
 SB—Brazil, Trinidad Id., and St. Paul Id.  
 SC—Chile  
 SD—Dutch Guiana  
 SE—Ecuador and Galapagos Archipelago  
 SF—French Guiana  
 SG—Paraguay  
 SH—British Guiana  
 SI—(Unassigned)  
 SJ—(Unassigned)  
 SK—Falkland Ids. and Falkland Dependencies  
 SL—Colombia  
 SM—(Unassigned)  
 SN—Ascension Id.  
 SO—Bolivia  
 SP—Peru  
 SQ—(Unassigned)  
 SR—(Unassigned)  
 SS—(Unassigned)  
 ST—(Unassigned)  
 SU—Uruguay  
 SV—Venezuela and Trinidad  
 SW—(Unassigned)  
 SX—(Unassigned)  
 SY—(Unassigned)  
 SZ—(Unassigned)

## AFRICA

FA—Abyssinia  
 FB—Madagascar, Reunion Id., Comoro Id., etc.  
 FC—Belgian Congo, Ruanda, Urundi  
 FD—Angola and Kabinda  
 FE—Egypt  
 FF—French West Africa, including French Sudan, Mauritania, Senegal, French Guinea, Ivory Coast, Upper Volta, Dahomey, Civil Ter. of the Niger, French Togoland, etc.  
 FG—Gambia  
 FH—Italian Somaliland  
 FI—Italian Libya (Tripolitania and Cyrenaica)  
 FJ—Somaliland Protectorate and Socotra  
 FK—Kenya, Zanzibar Protectorate, Uganda, Anglo-Egyptian Sudan, and Tanganyika Territory.  
 FL—Liberia  
 FM—Tunisia, Algeria, Morocco (including the Spanish Zone), Tangier  
 FN—Nigeria  
 FO—Union of South Africa, Northern and Southern Rhodesia, Bechuanaland Protectorate, and Southwest Africa  
 FP—Portuguese Guinea and Cape Verde Ids.  
 FQ—French Equatorial Africa and Cameroons  
 FR—Rio de Oro and adjacent Spanish Zones, Ifni, and Canary Ids.  
 FS—Sierra Leone  
 FT—Eritrea  
 FU—Rio Muni (Spanish Guinea) and Fernando Po  
 FV—French Somaliland  
 FW—Gold Coast Colony, Ashanti, Northern Territories and British Togoland  
 FX—Seychelle Dependencies  
 FY—(Unassigned)  
 FZ—Mozambique

## OCEANIA

OA—Australia (and Tasmania)  
 OD—Dutch East Indies\*  
 OE—Melanesia\*  
 OH—Hawaiian Ids.  
 OI—Micronesia\*  
 OO—Polynesia\*  
 OP—Philippine Ids.  
 OZ—New Zealand

\* To be further partitioned when activity warrants.

## SHIP STATIONS

Ship stations with amateur calls will place an X before their usual intermediate. E. g., Australian 3AA at sea, calling U. S. 1AW, would send "1AW NUXOA 3AA" The reply would be "3AA XOANU 1AW"